


TIME-SERT®

CORE DRILL REPAIR KIT

P/n 1812ECORESS117



P/N 1812ECORESS117

KIT CONTENTS

- 1) Step Core Drill J-42385-702C
- 2) Tap J-42385-703
- 3) Driver J-42385-704
- 4) 5 Inserts p/n 18122NF
M8x1.25x11.7mm Stainless


Use WD40 for drilling & tapping

-WARNING-

Cutting tools may shatter if broken. The wearing of safety glasses is required in the vicinity of their use.



1. Use the step core drill and drill until the stop collar touches the surface.




2. Tap to the full depth of hole. Try to keep tap as square to surface as possible.

Turn page over to continue



Using a few drops of 30wt motor oil
Oil the threads of the DRIVER.

**3. Screw an insert onto the driver then
into the prepared hole.**



**4. The driver will start to
tighten up as it expands the
bottom few threads of the
insert, continue turning until the
driver loosens up, remove driver
repair is complete.**